Driver Installation Manual for Windows 98®

The description applies to the following devices:

- **USB-Nano-485**
- **UBS-485-Nano/OP**

- **USB-485-Mini**
- **USB-485-Mini/OP**

- **USB-485-Mini/R**

- **Timi-USB**

The installation procedure is described by the example of the USB-485-Mini and is similar to all other devices.

CTI Commerzielle und Technische Informationssysteme GmbH

e-Mail: office@cti-lean.com

Max Liebermann Straße 184, 04157 Leipzig
Telefon: +49 /(0) 3 41 / 900 41 50
Telefax: +49 /(0) 3 41 /900 41 40

Homepage: www.cti-lean.com

Stand: 26. August 2010

Contents

USB Installation manual for Windows 98 2
Changing the COM Port number 5
Uninstallation manual for Windows 98 9

USB Installation manual for Windows 98

In case of questions or problems please contact us: E-mail office@cti-lean.com.
To install the driver it is not necessary to connect the *USB-485-Mini to the 485 Bus*.
Please connect the *USB-485-Mini* to the PC using the USB cord. The hardware assistant starts automatically.

If you want to continue the installation press **Next.**

Press **Next**.

Mark only CD-Rom drive. Insert the included CD into the drive and press **Next.**

Press **Next.**



The first part of the installation is finished. Press **Finish**

The creation of the USB serial port is done automatically.
The USB-485-Mini driver is now installed and the USB-485-Mini can now be used.

Changing the COM Port number

Over the Control panel you get to the System.



By installing the driver, the USB-485-Mini is inserted into the device manager under “universal serial bus controller“ and under “connections (COM and LPT)”.



To change the settings of the USB serial port, highlight the port, click on the **right mouse button** and choose **properties.**



Press **Port Settings**.



Press **Advanced**.



You can now change the COM connection number to the desired value.

Attention!!!
The new COM- connection number may not be assigned yet.

Uninstallation manual for Windows 98

Open Control panel and there **Software**. Search for an entry **USB-485-Mini**. Highlight it and choose **change/remove**.

Press **Continue**.



Press **Finish**.



Over Control panel you get to **System**. Open **Universal Bus Controller.** Highlight the **USB-485-Mini** and click on **remove**.

The Removal is now finished.